

integral™
LED

INSTALLATION INSTRUCTIONS
INSTALLATION INSTRUCTIONS
INSTRUCTIONS D'INSTALLATION
INSTALLATIE INSTRUCTIES
INSTRUCCIONES DE INSTALACIÓN
INSTALLATIONSANLEITUNG
INSTRUKCJE INSTALACJI
INSTRUÇÕES DE INSTALAÇÃO


Accent Pro Downlights



1

Connection/ Lien/ Verbinding/ Conexión/ Verbindung/ Połączenie/ Conexão

PRODUCT	Min. - Max. mA	Min. - Max. Vf
ILD150P	≤ 150	DC 30 - 36V
ILD175P	≤ 200	DC 30 - 36V
ILD195P	≤ 350	DC 30 - 36V
ILD120P	≤ 600	DC 30 - 36V




1.2


Supplier instructions / Consignes du fournisseur / Instructies van de leverancier / Instrucciones del proveedor / Lieferantenanweisungen / Instrukcje dostawcy / Instruções do fornecedor / Istruzioni del fornitore

2

Installation - with bezel / Installation / Installatie / Instalación / Installation / Instalacja / Instalação




a = Min. 50mm
b = Min. 50mm




PRODUCT	
ILD150P	Ø50mm
ILD175P	Ø75mm
ILD195P	Ø95mm
ILD120P	Ø120mm

3.1


ILD50P




ILD50 / 75 / 95 / 120P




3.2




3.3




3.4



3.5




3.6




3.7

ILD50P




ILD50 / 75 / 95 / 120P




4

Accessories / Accessoires / Accessoires / Accesorios / Zubehör / Akcesoria / Acessórias / Accessori


ILD50P




B.




C.



ILD50 / 75 / 95 / 120P



B.



Warranty/ Technical
& contact information
are all available at
www.integral-led.com

IS1014 B



All Trademarks Acknowledged

Integral LED is a division of Integral Memory plc:
Unit 6, Iron Bridge Close, Iron Bridge Business Park,
London, NW10 0UF, UK
Integral Europe BV, 2801 DG, NL