


integral™ LED

INSTALLATION INSTRUCTIONS
INSTRUCTIONS D'INSTALLATION
INSTALLATIE INSTRUCTIES
INSTRUCCIONES DE INSTALACIÓN
INSTALLATIONSANLEITUNG
INSTRUKCJE INSTALACJI
INSTRUÇÕES DE INSTALAÇÃO

True Solar - Solar LED Wall Light



IS 1001




ILSWLB004/ILSWLB005


1 Installation / Installation / Installatie / Instalación / Installation / Instalacja / Instalação

ILSWLB004/ILSWLB005


1.1




1.2



1.3



1.4








2 Function / Fonction / Functie / Función / Funktion / Funkciji / Função

ILSWLB004/ILSWLB005




Before first use




Mode A

25Lumen



Mode B

85Lumen




Mode C


115Lumen

3 Replaceable battery / Batterie remplaçable / Vervangbare batterij / Bateria reemplazable / Austauschbarer Akku / Wymienna bateria / Bateria substituível


3.1




3.2



3.3



3.4



Warranty/ Technical & contact information are all available at www.integral-led.com

ILSWLB004 ILSWLB005_V1



Integral LED is a division of Integral Memory plc:
Unit 6, Iron Bridge Close, Iron Bridge Business Park,
London, NW10 0UF, UK
Integral Europe BV, 2801 DG, NL