

integral LED

INSTALLATION INSTRUCTIONS
INSTRUCTIONS D'INSTALLATION
INSTALLATIE INSTRUCTIES
INSTRUCCIONES DE INSTALACIÓN
INSTALLATIONSANLEITUNG
INSTRUKCJE INSTALACJI
INSTRUÇÕES DE INSTALAÇÃO

T8 TUBE LIGHT



ILT8060AE001
ILT8120AE003
ILT8150AE004
ILT8180AE005
ILT8150AG009




HANDLE WITH CARE / MANIPULER AVEC SOIN / BREEKBAAR / TRATAR CON CUIDADO / MIT VORSICHT BEHANDELN / OSTROŻNIE / MANUSEIE COM CUIDADO / MANEGGIARE CON CURA

Do not use
with dimmers



Lamp suitable for 50Hz
or 60Hz operation



Lamp not suitable for
emergency operation



To be used with LED
replacement starter



To be used in dry conditions
or in a luminaire that
provides protection



- No modifications of the luminaire are to be made.
- This lamp may not be suitable for use in all applications where a traditional fluorescent lamp has been used. The temperature range of this lamp is more restricted. In cases of doubt regarding the suitability of the application the manufacturer of this lamp should be consulted.
- This lamp is designed for general lighting service.
- The LED replacement starter is included.
- The lamp is not suitable for operation with electronic ballasts and must only be used with a traditional magnetic ballast.

1

Installation / Installation / Installatie / Instalación / Installation / Instalacja / Instalação / Installazione

